



Prep Substrate

- GAF Cleaning Concentrate
- Power washer
- Blower
- Squeegee/broom

Prime (where required)

- Primer
- Extension cord
- 1/2" drill (for mixer)
- Paddle mixer/mixing stick

Seam Details (GAF Silicone Mastic)

Check with GAF Technical Sales Rep for specific seam treatment instructions.

- Pourable paint bucket
- 4" rollers, frame & covers
- Extendable roller pole



Silicone Top Coat (GAF High Solids Silicone)

- Mil gauge
- 1/2" drill (for mixer)
- Paddle mixer
- Squeegee (notched for smooth/flat for rough)
- 2 extendable poles
- 9" or 18" heavy duty roller frames
- 1 1/4" nap rollers

Don't Forget the Accessories:

- Gloves
- Protective eyewear
- Virgin mineral spirits or VM&P naphtha
- Masking tape & masking paper
- Rags
- Shoe covers
- Chip brushes
- Contractor-grade trash bags

