



**Notes:**

1. Clean metal and membrane with EverGuard® TPO Seam Cleaner and allow to dry. Once dry, prime metal and membrane with EverGuard® TPO Primer before installing EverGuard® TPO Cover Tape.
2. Edge metal should be designed for wind resistance in accordance with the applicable edition of ASCE 7 and tested for capacity in accordance with the test methods in the applicable edition of ANSI/SPRI ES-1.
3. For steel roof decks: Fill steel deck flutes with closed cell spray foam insulation prior to the installation of above deck insulation a minimum of 12" [305 mm] from face of wall on each side.

LEGEND	
	ADHESIVE
	SEALANT
	PRIMER

## Metal Roof Edge with Cover Tape

Roof Area: Roof Edge	
Issue Date: 11/13/2023	Scale: N.T.S.

Detail No:  
**202C**