



**Notes:**

1. Clean metal and membrane with EverGuard® TPO Seam Cleaner and allow to dry. Once dry, prime metal and membrane with EverGuard® TPO Primer before installing EverGuard® TPO Cover Tape.
2. Edge metal should be designed for wind resistance in accordance with the applicable edition of ASCE 7. Additional requirements apply for guarantee coverage of attachment to insulated metal wall panels. Contact [coldstorage.assistance@gaf.com](mailto:coldstorage.assistance@gaf.com) for details.
3. For steel roof decks: Fill steel deck flutes with closed cell spray foam insulation prior to the installation of above deck insulation a minimum of 12" [305 mm] from face of wall.

LEGEND	
	ADHESIVE
	SEALANT
	PRIMER

## Metal Roof Edge with Cover Tape at I.M.P. Wall

Roof Area: Roof Edge	
Issue Date: 11/13/2023	Scale: N.T.S.

Detail No:  
**203D**